



XP95 MOUNTING BASE (BLACK).

PART No. 45681-361



Wiring Diagram of XP95 Detector



Schematic Wiring Diagram of XP95 Detector With a Common Remote led


Earth Terminal is Provided for Easier Installation. It is Not Required by the Detector head.

Refer To Apollo Engineering Product Guide For Full Technical Information APOLLO FIRE DETECTORS LIMITED, 36 BROOKSIDE ROAD, HAVANT, PO9 1JR ENGLAND




XP95 MOUNTING BASE (BLACK).

PART No. 45681-361



Wiring Diagram of XP95



Schematic Wiring Diagram of XP95 Detector Circuit With a Common Remote led

Earth Terminal is Provided for Easier Installation It is Not Required by the Detector head.


Refer To Apollo Engineering Product Guide For Full Technical Information

APOLLO FIRE DETECTORS LIMITED, 36 BROOKSIDE ROAD, HAVANT, PO9 1JR ENGLAND




XP95 MOUNTING BASE (BLACK).

PART No. 45681-361



Wiring Diagram of XP95 Detector



Schematic Wiring Diagram of XP95 Detector With a Common Remote led


Earth Terminal is Provided for Easier Installation. It is Not Required by the Detector head.

Refer To Apollo Engineering Product Guide For Full Technical Information APOLLO FIRE DETECTORS LIMITED, 36 BROOKSIDE ROAD, HAVANT, PO9 1JR ENGLAND




XP95 MOUNTING BASE (BLACK).

PART No. 45681-361



Wiring Diagram of XP95



Schematic Wiring Diagram of XP95 Detector Circuit

With a Common Remote led

Earth Terminal is Provided for Easier Installation It is Not Required by the Detector head.

Refer To Apollo Engineering Product Guide For Full Technical Information

APOLLO FIRE DETECTORS LIMITED, 36 BROOKSIDE ROAD, HAVANT, PO9 1JR ENGLAND