



PRINTER BUS MODULE (APR-PRT1) USER'S GUIDE

Introduction

The Printer Bus Module provides you with the ability to manually print specific events that have occurred in your Spectra system. The events can be printed through a dot matrix printer connected to the module's parallel port or its serial port.

Setting APR-PRT1 Time & Date

When the Printer Bus Module is connected to a Spectra system, the module's internal clock must be set manually. To do so:

1. Press **[ENTER]** from your Spectra keypad.
2. Enter your **[MASTER CODE]**.
3. Enter section **[110]**.
4. Enter the 4-digit **[YEAR]** (Ex: 2000, etc.).
5. Enter the 2-digit **[MONTH]**.
6. Enter the 2-digit **[DAY]**.

*Example: You wish to set the date as June 4, 2000. After entering section **[110]**, you would enter: 2000 (year), 06 (month) and 04 (day). If the keypad emits a rejection beep, there is an error. If so, try again.*

Manually Printing System Events

The Printer Bus Module gives you the ability to manually print specific system events that have occurred. For example, you wish to print a report of all the Arming and Disarming events (all the times that your Spectra system has been armed and disarmed) that have already occurred in your system. To do so:

1. Press **[ENTER]** from your Spectra keypad.
2. Enter your **[MASTER CODE]**.
3. Enter the 3-digit **[SECTION]** (See Table 1).
4. Press **[ENTER]**.

Upon completing Step 4, the Printer Bus Module will commence printing all the system events that have occurred.

Table 1: System Event Sections

Section	System Events to be printed
[111]	Arm & Disarm Events
[112]	Alarm & Alarm Restore Events
[113]	Tamper & Tamper Restore Events
[114]	Trouble & Trouble Restore Events
[115]	Miscellaneous Events*

* = **[PG]** & **[FNC1]** keys pressed, Button pressed on Remote, Bypass programming, User Activated PGM, Breaching Zone w/ Delay and System power up.